

LASER PEGS®

The Ultimate Construction Toy For Kids®

**GI700B
SPIDER KIT
AGES 5+**

12 Models+
Any creation you can build

LIGHTED
CONSTRUCTION SET INCLUDES:

- 15 Laser Pegs®
- 148 Construction Parts
- Laser Pegs® Power Cord
- Triangle Power Base
- Instruction Manual
- Requires 3-AA Batteries

Batteries NOT
Included


EN71, RoHS COMPLIANT

This product complies to
all safety requirements
of ASTM F 963


**WARNING:
CHOKING HAZARD**-Small parts.
Not for children under 3 yrs.
Do not submerge in water.

MODEL INSTRUCTIONS

All additional model instructions can
be downloaded at www.LaserPegs.com




Color Code Each Laser Peg® is color coded on the circuit board inside each shape. There is No LED In The 90 Degree Peg.



Sound Activated
Triangle Power Base




Laser Pegs®
Peg Cord



www.LaserPegs.com

This manual is copyright and cannot be reproduced or used online without Laser Pegs® Ventures LLC permission. Copyright 2014 © All Rights Reserved US Patent #7,731,558 Additional Global & Multiple Patents Pending. Laser Pegs® Ventures LLC. 8304 Consumer Ct Sarasota FL 34240. Contact: Support@LaserPegs.com

Connecting Pegs



To construct with Laser Pegs®, slide two pieces together to form a connection. Slide each piece on and off smoothly. The 90° Pegs are essential to construction but they DO NOT LIGHT UP.

Environmental Phenomena


* The unit may malfunction if subjected to radio-frequency interference. It SHOULD revert to normal operation when the interference stops. If not, it may become necessary to turn the power off and back on, or remove and reinstall the batteries.

* In the unlikely event of an electrostatic discharge, the unit may malfunction and lose memory, requiring the user to reset the device by removing and reinstalling the batteries.

Push Red Power Button to turn on/off

Push Red Power Button to cycle through 4 different light settings.

SOUND/ON/FLASH/FLASH FASTER




**WARNING: STROBE LIGHTS
MAY CAUSE SEIZURES**

The toy is not to be connected to more than the recommended number of power supplies

Replacing Batteries

1. Remove the three (3) screws.
2. Place three (3) AA batteries in the correct position - as displayed inside the Triangle Power Base.
3. Reassemble the Triangle Power Base.
4. Replace the three (3) screws.
5. Push RED Power Button to turn on!
6. Do not mix old and new batteries.
7. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium, NiMH) batteries!
8. Exhausted batteries are to be removed from the Triangle Power Base.
9. Never connect more than 200 Laser Pegs®
10. Non-rechargeable batteries are not to be recharged.
11. Rechargeable batteries are only to be recharged under adult supervision.
12. Rechargeable batteries are to be removed from the toy before being recharged.
13. Batteries are to be inserted with the correct polarity.
14. The supply terminals are not to be short-circuited.
15. DO NOT THROW BATTERIES INTO FIRE!

Remove the 3 Phillips head screws



3-AA Batteries


Remove the three Phillips head screws with a 4mm screw driver.
Requires (3AA) Batteries

Please dispose of batteries properly as per state and local regulations.

Using an AC Adapter

Remove all batteries from Laser Pegs® power base before using the 5-volt AC adapter.

*To avoid short-circuits, keep metal objects and other unauthorized materials from obstructing the peg holes.



When using an AC Adapter, NEVER place the adapter plug into the Triangle Power Base top peg holes.

Never connect more than 200 Laser Pegs® when using a 5-volt (2000mA) AC Adapter.

The AC adapter and the Triangle Power Base are to be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired.

WARNING! Each Laser Peg® draws current from the batteries. Therefore, the more pegs you use, the quicker you will deplete your battery power! As the power weakens, the current will slowly fail and some Laser Pegs® will illuminate (typically the reds and yellows) and some won't. When the Laser Pegs® dim the Laser Pegs® are not broken, they just need stronger batteries or an AC Adapter.

You have 3 simple options...

1. Use a 5-volt AC Adapter - available from www.LaserPegs.com
2. Change the batteries.
3. Use high quality batteries. They will last a little longer, but they will still deplete rapidly the more laser pegs you connect!

DO NOT SUBMERGE IN WATER


PRAYING MANTIS: A thin predatory insect with prayerfully folded spiky forelegs.




PRAYING MANTIS

Model
Difficulty
Level


3




STEP
3




A




B




STEP
1




STEP
2




STEP
4



STEP
5



STEP
6



COMBINE
PARTS




FLIP MODEL
OVER




ROTATE
MODEL


STEP
7




STEP
8





STEP
9




STEP
10




STEP
11




STEP
12




STEP
13




STEP
14




STEP
15




STEP
16




STEP
17




STEP
18




STEP
19




D




STEP
20




STEP
21




STEP
22




STEP
23




STEP
24




STEP
25




STEP
26




STEP
27




STEP
28




STEP
29




STEP
30




STEP
31




STEP
32




STEP
33




STEP
34




STEP
35



STEP
36




STEP
37




STEP
38




A




STEP
39




STEP
40




STEP
41



STEP
42



STEP
43



FCC Notice:
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:
1) This device may not cause harmful interference, and
2) This device must accept any interference received, including interference that may cause undesired operation.

CAN ICES-3 (B) / NMB-3 (B)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Laser Pegs® CARES
Questions? Comments?
For additional compliance info:
1-866-432-3735
Contact: Support@LaserPegs.com

MADE IN CHINA

www.LaserPegs.com
Copyright 2014 © All Rights Reserved Global & Multiple Patents Pending.
US Patent #7,731,558