


LASER PEGS®

The Ultimate Construction Toy For Kids®

NATIONAL GEOGRAPHIC™
DINOSAURS
Ages 5 +

Please read this manual before you begin! Failure to follow this manual's instructions may result in damage to the Triangle Power Base, AC Adapter and/or Laser Pegs®. Not adhering to these instructions will void the manufacturer's warranty. The packaging must be kept because it contains important information.

WARNING: CHOKING HAZARD—Small parts. Not for children under 3 yrs. Do not submerge in water.



Construction Compatible

Requires 3-AA Batteries

Compatible with other construction kits

Batteries NOT Included

EN71, RoHS COMPLIANT


This product complies to all safety requirements of ASTM F 963

MODEL INSTRUCTIONS

All additional model instructions can be downloaded at www.LaserPegs.com

Laser Pegs® Parts List


There is No LED In The 90 Degree Peg



Each Laser Peg® is color coded on the circuit board inside each shape. There is No LED In The 90 Degree Peg.




Laser Pegs® Link that allows you to connect to other construction kits.



Sound Activated Triangle Power Base




Laser Pegs® Peg Cord



www.LaserPegs.com

This manual is copyright and cannot be reproduced or used online without Laser Pegs® Ventures LLC permission. © Copyright 2014. All Rights Reserved US Patent #7,731,558 Additional Global & Multiple Patents Pending. Laser Pegs® Ventures LLC. 8304 Consumer Ct Sarasota FL. 34240. Contact: Support@LaserPegs.com

Connecting Pegs



To construct with Laser Pegs®, slide two pieces together to form a connection. Slide each piece on and off smoothly. The 90° Pegs are essential to construction but they DO NOT LIGHT UP.

Environmental Phenomena


* The unit may malfunction if subjected to radio-frequency interference. It SHOULD revert to normal operation when the interference stops. If not, it may become necessary to turn the power off and back on, or remove and reinstall the batteries.

* In the unlikely event of an electrostatic discharge, the unit may malfunction and lose memory, requiring the user to reset the device by removing and reinstalling the batteries.

Push Red Power Button to turn on/off

Push Red Power Button to cycle through 4 different light settings.

SOUND/ON/FLASH/FLASH FASTER




WARNING: STROBE LIGHTS MAY CAUSE SEIZURES

Replacing Batteries

1. Remove the three (3) screws.
2. Place three (3) AA batteries in the correct position - as displayed inside the Triangle Power Base.
3. Reassemble the Triangle Power Base.
4. Replace the three (3) screws.
5. Push RED Power Button to turn on!
6. Do not mix old and new batteries.
7. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium, NiMH) batteries!
8. Exhausted batteries are to be removed from the Triangle Power Base.
9. Never connect more than 200 Laser Pegs®
10. Non-rechargeable batteries are not to be recharged.
11. Rechargeable batteries are only to be recharged under adult supervision.
12. Rechargeable batteries are to be removed from the toy before being recharged.
13. Batteries are to be inserted with the correct polarity.
14. The supply terminals are not to be short-circuited.
15. DO NOT THROW BATTERIES INTO FIRE!

Remove the 3 Phillips head screws



3-AA Batteries




Remove the three Phillips head screws with a 4mm screw driver. Requires (3AA) Batteries

Please dispose of batteries properly as per state and local regulations.

Using an AC Adapter

Remove all batteries from Laser Pegs® power base before using the 5-volt AC adapter.



When using an AC Adapter, NEVER place the adapter plug into the Triangle Power Base top peg holes.

*To avoid short-circuits, keep metal objects and other unauthorized materials from obstructing the peg holes.

Never connect more than 200 Laser Pegs® when using a 5-volt (2000mA) AC Adapter.

The AC adapter and the Triangle Power Base are to be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, they must not be used until the damage has been repaired.

WARNING! Each Laser Peg® draws current from the batteries. Therefore, the more pegs you use, the quicker you will deplete your battery power! As the power weakens, the current will slowly fail and some Laser Pegs® will illuminate (typically the reds and yellows) and some won't. When the Laser Pegs® dim the Laser Pegs® are not broken, they just need stronger batteries or an AC Adapter.

You have 3 simple options...

1. Use a 5-volt AC Adapter - available from www.LaserPegs.com
2. Change the batteries.
3. Use high quality batteries. They will last a little longer, but they will still deplete rapidly the more laser pegs you connect!

DO NOT SUBMERGE IN WATER



PARASAUROLOPH: The parasaurolaph is often called the trumpet dinosaur for the honking sound it produced when blowing air through the large, curved crest on its head.




PARASAUROLOPH

Model Difficulty Level


4




STEP 1




STEP 2




STEP 3




STEP 4




B



STEP 5



STEP 6



Laser Pegs® CARES

Questions? Comments?

For additional compliance info:


1-866-432-3735

Contact: Support@LaserPegs.com



www.LaserPegs.com

Copyright 2014 © All Rights Reserved Global & Multiple Patents Pending. US Patent #7,731,558

STEP
7




STEP
8




STEP
9




STEP
10




STEP
11




STEP
12




STEP
13




STEP
14




STEP
15




STEP
16




STEP
17




STEP
18




STEP
19




STEP
20




STEP
21



STEP
22




STEP
23




STEP
24



COMBINE B




STEP
25




STEP
26




STEP
27




STEP
28




STEP
29




STEP
30




STEP
31




STEP
32




STEP
33




STEP
34



STEP
35




STEP
36




www.LaserPegs.com

Copyright 2014 © All Rights Reserved Global & Multiple Patents Pending.
US Patent #7,731,558


STEP
37




STEP
38




STEP
39




STEP
40




STEP
41





STEP
42




STEP
43




STEP
44




STEP
45




STEP
46




STEP
47




STEP
48




STEP
49




STEP
50




STEP
51







STEP
52




STEP
53




STEP
54




STEP
55




STEP
56




STEP
57 COMBINE A




STEP
58




STEP
59



STEP
60



STEP
61



NATIONAL GEOGRAPHIC KIDS and Yellow Border Design are trademarks of the National Geographic Society, used under license. All rights reserved.



National Geographic's net proceeds support vital exploration, conservation, research, and education programs.

www.LaserPegs.com

Copyright 2014 © All Rights Reserved Global & Multiple Patents Pending.
US Patent #7,731,558

